



User Guide




SoundPro X40 Headphones

Congratulations on purchasing the Pii Tech SoundPro X40 Wireless Bluetooth Headphone!

This User guide provides essential information to help you set up, operate, and maintain your device, ensuring optimal performance and longevity. Please read this guide thoroughly before using your headphone.

1. Know your device



2. Charging the device

Before initial use, charge your headphone. Connect the charging cable to the charging port on the headphone and plug the USB end into a standard USB power adapter (5V/1A recommended) or a computer's USB port. The indicator light will glow 'Red' while charging and will turn off when fully charged.

Note - If the power of the headphone is fully discharged / very low, or it has been kept unused for many days, there will be a period of battery pre-charging time and the headphone will take some time before charging.

3. Pairing your headphone with your Bluetooth audio device

To use your headphone in wireless mode, it must be paired with a compatible Bluetooth device such as a smartphone/ tablet / laptop/ TV/ etc.

1. **Switch On the headphone:** Long Press the Power On / Off (Ⓢ) button for 3 seconds to switch On the headphone. A 'Red' & 'Blue' flashing light indicates the headphone is in pairing mode.
2. **Enable the connecting device's Bluetooth:** Ensure the Bluetooth of the connecting device (smartphone/ tablet / laptop/ TV/ etc.) is enabled.
3. **Connect your device to the headphone through Bluetooth:** On your device, search for Bluetooth devices and select the wireless headphone ("Wireless") from the list of discovered Bluetooth devices. When the headphone is successfully connected, its indicator light will slow flash in 'Blue' colour and it will give a prompt saying "Connected".

The headphone can now be used with your connected device to listen to music/ videos, take calls, and control volume/ playlists.

4. Using your headphone in wired connection with an audio device

This headphone can also be used in wired mode, to connect to any compatible Audio devices

1. **Switch On the headphone:** Long Press the Power On / Off (Ⓢ) button to switch On the headphone.
2. **Connect Audio cable to AUX In:** When the headphone is powering On, insert the audio cable (with 3.5mm audio jack) into the AUX IN port of the headphone. Connect the other end of the Audio Cable to the compatible audio device (smartphone/ tablet / laptop/ TV/ MP3/ any other external audio input).

The headphone can now be used with your connected device to listen to music/ videos, take calls, and control volume/ playlists.

5. Operating the Headphone

- **Switch On/ Off:** Long Press (for 3 seconds) the Power On (Ⓢ) button to switch on the headphone.
- **Taking a call:** When connected to a smartphone and there is an incoming call, Short Press the Answer Call button to answer the call OR Long Press the Answer Call button to reject the call. You can double Press the Answer Call button to call back the last number.
- **Volume control:** When connected to a compatible device, Long Press the (+) Vol Up Button to increase volume and Long Press the (-) Vol Down Button to decrease volume.
- **Next / Previous Song:** When connected to a compatible device, Short Press the (▶▶ ||) Next Button to move to the next song and Long Press the (||◀◀) Previous Button to move to the previous song.
- **Play/ Pause:** When connected to an audible device, Short Press the Play/ Pause (▶||) button to Pause/ Play the audio/ video.
- **Using external storage (TF Card):** Insert a TF Card in the TF Card Port and press the (M) Mode button to go to TF Card Mode. Use above operating buttons to Play and control audio directly from the Card.

6. Maintenance

6.1 Cleaning your headphone

Regularly clean your headphone to ensure proper function and hygiene.

- Wipe the body with a soft cloth.
- For stubborn dirt, slightly dampen the cloth with water. Do NOT use water/ liquid or any harsh chemicals or abrasive materials to clean the headphone.
- Ensure the charging contacts are clean and dry before charging.

6.2 Battery Care

- Avoid extreme temperatures, which can degrade battery life.
- Do not leave the headphone fully discharged for extended periods.
- Use only the provided charging cable or a certified replacement to charge the headphone.

5. Troubleshooting

If you encounter issues with your Headphone, refer to the following common solutions:

| Problem | Solution |
|---|--|
| Headphone not turning on | <ul style="list-style-type: none">• Ensure the headphone is fully charged.• Press and hold the Power On/Off button for at least 10 seconds. |
| Headphone not charging | <ul style="list-style-type: none">• Please make sure that the charging cable is correctly connected.• When the power of the headphone is very low, there will be a period of battery pre-charging time and the headphone will take some time before charging. |
| Unable to pair the headphone with devices | <ul style="list-style-type: none">• Check if Bluetooth is enabled on your device and the headphone.• Please make sure that the headphone is powered and is not connected by any other smart phone/ device(s).• Move the headphone close to the connecting device and search again. If it still does not connect, turn off the Bluetooth of the connecting device and turn it on again after 20 seconds; try re-connecting.• Restart both the device and headphone, and re-try connecting. |